

# Spitronics - ECU - Testing Hall Crank Sensors - Guide

## 1. Overview

This document helps diagnose problems with **Hall / optical crank trigger sensors**.

👉 Work through each step in order.

---

## 2. Function / Concept

A Hall sensor provides a **digital switching signal**:

- ON/OFF voltage signal (typically 0V ↔ 12V)
- Requires:
  - Power supply
  - Ground
  - Signal output

ECU requires:

- Clean switching signal
- Stable RPM
- Clear voltage transition

If signal is:

- Missing → No RPM
  - Weak / partial → No detection
  - Noisy → Erratic RPM
- 

## 3. Setup / Configuration

Before testing, ensure:

### 3.1 Basic ECU Setup

- Startup procedure completed
- Only **P1** connector connected
- All other connectors disconnected
- Comms cable connected
- ECU connected to software

### 3.2 Firmware

- Correct firmware for trigger pattern loaded
- Verify via **Device Information** button

### 3.3 Jumper Settings

- Set for **Hall sensor**

Callisto:

- 12V position
- 2-pin jumper **CLOSED**

Mercury2:

- 2-pin jumper **CLOSED**

△ Note: Jumper location may be opposite than other products

### **3.4 Battery Voltage**

- Cranking voltage:
  - ✓ Good:  $\geq 11V$
  - △ Weak:  $< 10V$
  - ✗ Problem:  $< 9V$

Low voltage causes:

- Weak switching signal
- ECU may not detect transitions

**i** See: Power Connection

---

## **4. Practical Procedure**

### **4.1 Check for Errors**

- Check error display (bottom of screen)
- Resolve all errors first

**i** See: Error Codes

---

### **4.2 Check RPM Signal**

Crank engine and observe RPM:

- ✓ 100–300 RPM → OK
- ✗ No RPM → No signal
- △ Erratic RPM → Do NOT start

Possible causes:

- Incorrect edge setting
- Wrong firmware
- Electrical interference
- Mechanical interference

### **4.3 No RPM Condition**

If:

- No errors

- No RPM

👉 ECU is not detecting crank signal

Proceed to sensor testing

## 4.4 Sensor Size vs Trigger Wheel

Ensure correct matching:

- Sensor magnet must be **smaller than tooth gap**
- Oversized sensing area:
  - Weak signal
  - Poor resolution


👉 Quick check:

- Use iron filings on sensor tip
- Shows sensing diameter

Possible fixes:

- Increase sensing gap (if signal strong enough)
- Use smaller sensor
- Use lower tooth count wheel

## 5. Sensor Testing



⚠ Hall sensors require **power to operate**

👉 Cannot be tested like magnetic sensors

### 5.1 Ground Continuity

- Measure ECU ground → sensor ground
- Expected: **0 ohms**

### 5.2 Power Supply Continuity

- Measure sensor power → ignition supply
- Expected: close to **0 ohms** (filter components inside ECU)

### 5.3 Signal Wire Continuity

- Measure sensor signal → ECU input (P1 - Pin 12)
- Disconnect P1 if needed

⚠ Do not damage female pins

---

### 5.4 Power Check (Live Test)

- Connect P1
- Switch ignition ON

Measure at sensor:

- Negative ↔ Positive

Expected:

- ~12V DC

### 5.5 Signal Switching Test

- Measure: sensor signal ↔ negative

Expected:

- ~12V (no target)
- ~0V when metal target present

⚠ Logic may be inverted on some sensors

✓ Only requirement: clear voltage change

If voltage does NOT drop below ~1V:

- ECU will not detect signal

### 5.6 Pull-up Test

If no signal voltage:

- Check pull-up jumper is **CLOSED**

If still no voltage:

- Disconnect signal wire
- Measure ECU side

Results:

- ✓ 12V present → sensor faulty (shorting signal)
- ✗ No 12V → ECU pull-up not active

### 5.7 Cranking Signal Test

- Sensor installed
- Measure signal ↔ negative
- Set meter to AC volts
- Crank engine

Expected:

- ~12V AC switching signal
- 

## **6. Errors During Starting / Running**

### **6.1 Ignition Interference**

- Incorrect signal edge setting, Falling ↔ Rising
- Coils create spikes
- Sensor wiring must be screened

👉 Screen grounded at ECU only

### **6.2 ECU Reset**

Symptoms:

- ECU restarts
- Software disconnects

Causes:

- Power supply issue
- Relay wiring

### **6.3 High RPM Errors**

Possible causes:

- Buckled trigger wheel
- Unbalanced wheel
- Large sensing gap
- Small tooth pitch
- Large sensor sensing area

Additional:

- Sensor may require pull-up resistor
- Sensor may 5V Type → Needs slight modification

👉 Add 1kΩ resistor:

- Signal → Positive

### **6.4 Test Signal**

- Ensure **test signal is OFF**

### **6.5 Signal Fade**

RPM drops or fades:

Possible causes:

- Incorrect sensor gap

## **6.6 Spark Plug Interference**

Incorrect components can cause noise:

- Use:
  - Resistor plugs for COP
  - Non-resistor plugs for HT leads
- Use:
  - Carbon HT leads
  - NOT copper leads

Check in dark:

- Look for arcing

👉 Keep sensor wiring away from HT leads

---

## **7. Notes / Warnings**

⚠ Hall sensors require correct power supply

⚠ No switching = no RPM

⚠ Weak switching = unreliable signal

## **8. Reference Links**

**i** More Info:

- Hardware Manuals → Jumper Settings
- Hardware Manuals → Power Connection
- Troubleshooting Guides → Error Codes