



# Tiptronic Switches Drawing

Harness Required: M74-P4

Last Changed: 26/02/2026



Harness Pin View

1. Blue/White
2. Blue - Down Switch
3. Back - Ground
4. Blue
5. Red - Up Switch
6. Red

Connector Pinouts