



Speed Sensor Wiring


Last Changed: 08/08/2020
Harness: OT01-P1 or OT02-P1




Magnetic Speed Sensor




Hall or Optic Speed Sensor




Magnetic Speed Sensor Tap-In and filter



Note! Optional Capacitors from reference to black will help prevent interference in ECU earth differences.
If not used, leave the black un-connected and isolate.



Hall or Optic or Tacho Speed Sensor Tap-In and filter



Note! Optional Capacitors from reference to black will help prevent interference in ECU earth differences.
If not used, leave the black un-connected and isolate.

Software Settings

Active Sensors

☒ RPM

☒ Speed